

INDICATOR STATION DEFAULT CODES

The factory default access codes for the Indicator Station are as follows:

User Code: 1234

Set-up Code: 2468

WARNING MESSAGES

If any station misses the routine heart beats, the Indicator Station display a **'Heart Beat Missed'** on the main screen.

If the station repeatedly misses routine heart beats, the Indicator Station will display the warning: **"Signal lost"**. The station should be located, checked and repositioned if necessary. Return to the Indicator Station and reset.

FIRE ALARMS

In the event of fire, the alarm is raised by operating the switch on any Howler alarm. All alarms will the sound, and the premises should be evacuated. The Indicator Station will display the number of which Howler alarm or detector has been operated. The responsible person should check whether the alarm is genuine.

To **silence** the alarms.



The Indicator Station will continue to emit a warning beep until it is reset.

In order to **reset** the system, the Howler alarm which has been activated needs to be reset prior to resetting the Indicator Station. The method of resetting the Howler alarm will depend on the model. 'Push button' models (HO6 and HO7), are reset by pressing the button a second time.

For Howler alarms incorporating a traditional key-resettable 'call point', reset by inserting the black plastic 'key' into the circular hole in the base of the call point and turning clockwise until the call point resets and the yellow strip is hidden.

Once the Howler has been reset, return to the Indicator Station and reset:



NB: If the Indicator Station is reset without first resetting the Howler alarm, the system will resound.

If a detector has triggered the alarm, the system should not be reset until the cause of alarm has been removed (smoke, dust or heat).

2.2 First Aid Alarms

If First Aid assistance is required, the operator simply presses the green button on the Howler, which will illuminate. A message is displayed on the Indicator Station stating "ASSISTANCE REQUIRED" and the station number. The first aid responder at the Indicator Station should acknowledge receipt of the message by pressing ENTER. The LED Halo on the operated station will flash to indicate that assistance is on its way. To reset the alarm, the operator must attend the station and reset the green button. This will reset the system.